

# Use and Operation Guide

## ***Wrong Way Warning Systems***

Applies to the following assemblies:

**M75-DETC A-M000**  
**M75-DETOA-0000**

This guide is designed to assist in the installation of  
TraffiCalm's Wrong Way Warning Systems:

- System Design
- Theory of Operation
- Installation
- System Configuration
- Validation Testing
- Notification Monitoring
- Maintenance

In addition to this guide, installation manuals and supplements have been delivered with the product. These are also available at [Trafficalm.com/wwa](http://Trafficalm.com/wwa).

TraffiCalm greatly appreciates your investment in our solutions, if at any time you require additional assistance feel free to give us a call at 855-738-2722

## Components:

All TrafficCalm™ Wrong Way Warning + Notification Systems consist of these basic elements:

- **Controller** (M75-DETC-A-M000 or M75-DETOA-0000)
- Multiple **Collaborators**
- Radars
- Power Supplies
- LED Sign Enhancement Rings or RRFBs

Additional accessories include

- Expanded-use power supplies (low temp, solar, etc)
- Internally-illuminated signs with LED enhancement rings
- other detection methods (loops, for example)

## System Layout

A single Wrong Way **Controller** works in conjunction with at least one **Collaborator** (and up to 12) to create a network that covers a road section (typically a ramp) in consistent detection, resulting in timely warning to drivers and, if equipped, reliable notification to your designated monitoring team.

Detection is accomplished with up to eight (8) radar detector units. Each radar unit is connected to either the Controller or a Collaborator.

Radars (and their respective Collaborator) are configured into one of 4 detection “zones”

1. Flasher Activation Zone
2. Pre-Alert Zone
3. Alert Zone (always shared with the Controller)
4. Confirmation Zone

As noted above, the Controller is **ALWAYS** in the Alert Zone

What it all looks like

*Radar*

*Collaborator*

*Controller (with Camera)*

*Enhanced Wrong Way Sign*

*Reason we need wrong way mitigation*



# (System Design)

In anticipation of your project we supplied design guides (example shown below) that itemized the hardware used per specific road section (typically a ramp) and per post. This guide is critical to the success of the installation and should be available for reference during the planning and installation phases. After the installation, this guide can be referenced during maintenance and, if needed, repair.



example of design guide/pictorial

The design guide portrays the functionality of our system and how the specific components will need to be placed in order to perform well for the given ramp.

The design guide was created remotely, with information at hand. Locally exclusive information may dictate change orders to the design of the system, these should be noted and updated on the design guide.

Note that the visualized radar aiming is approximate, further in this guide we will cover radar aiming theory.

### LED Sign Enhancements:

The supplied sign enhancements are made to install to any Wrong Way or Do Not Enter sign manufactured to MUTCD requirements. They can be highlighted in either red or white LEDs and are designed to provide ample warning to any wrong way driver in almost any condition, day or night.

The LED enhancements can be connected to any Controller or Collaborator in the system. Up to 8 can be collocated with the radars; an additional 4 sign enhancements can be added to Collaborators in a "Flasher Only" grouping.

LED flashing will only occur upon succesful detection of a wrong way vehicle



LED intensity is hard to photograph

### Before installing the system...

The three main goals of any wrong way mitigation system:

- 1. Detect Wrong Way Drivers (WWDs) in any condition*
- 2. Prompt WWDs to self correct and safely turn around*
- 3. Notify monitoring facilities if a WWD does not self correct (only available on the M75-DETCA-M000 model)*

Trafficalm has developed a proven system that can accomplish all three with minimal hardware and stellar performance

Performance must be measured by two factors:

- 1. Ability to warn any wrong way driver*
- 2. Ability to send undeniable evidence of a WWD's activity to a system or person that can act upon the reported activity*

Wrong Way Warning + Notification has been developed to make installation not only easy, but nearly foolproof. However, it is still important to understand a few core concepts...

### RADARS

We use many "small" radar detectors to create up to 4 zones of detection. While each zone can consist of a single radar, it is highly recommended that two make up the zone.

The more radars and zones that are incorporated the more accurate a system can be considered. It is entirely viable to create a system with just one radar, but the chance for false detections increase dramatically. Adding a second radar will halve the occurrence of false calls, a third will halve it again. Typically, a complete system that can deliver at least a 99.5% accuracy rate consists of 4 radars in two zones.


Somewhat counter-intuitively, our radars are aimed at a very sharp angle down at the roadway, and a very sharp angle inward toward the center of traffic. We will cover more of this concept in the installation section.

## Collaboration

The Controller wirelessly receives all the detection data from the radars. This information is validated by a collaboration algorithm that determines whether a notification should be sent or not. The stages as a wrong way driver passes through the zones is as follows:

1. First zone (flasher only) breach results in all signs flashing
2. Second zone (pre-alert or alert) breach results in notification being sent unless a third zone is incorporated.
3. Third zone breach (alert) sends notification unless a fourth zone is incorporated.
4. Fourth zone (confirmation) breach sends notification.

How does it work? The system's algorithm considers the vehicle speed and distance travelled (determined by series of detections). A real vehicle will have a predictable signature of detection which can be relied upon for sending notification.



example of typical 2 zone, 4 radar setup

# ⟨Installation⟩

## Introduction

Typically most systems are installed at this point. However, it is still beneficial to understand how the individual components are deployed in the field, especially where maintenance will be required.

In this section we will detail each component and notes on its installation.

Typical installation procedure...

1. Affix LED enhancement ring to sign face (if needed)
2. Install Controller or Collaborator
3. Install supporting power supply (solar panel, battery box, AC inverter, etc.)
4. Install Radar high on post
5. Install sign and LED enhancement ring to post
6. Make all connections between devices
7. Power on Collaborators
8. Power On Controller
9. Configure System

**NOTE: It is prudent to take note of each Collaborator's ID number and location before installing on the post!**

## Mounting Methods

Various methods can be used to mount our components. An installation kit is supplied which contains bolts for mounting to square posts and banding brackets for mounting to round posts or unusual infrastructure. No banding or banding tool is supplied. Where banding is used, it is recommended that 3/4" banding be double wrapped to ensure maximum stability in windy and icy conditions.

Some of our solar panel brackets require large u-bolts (not supplied) not readily available. It is highly recommended this be planned for and purchased accordingly. They are the best possible way to mount our solar panels to ensure years of trouble free service.

---


**ALWAYS ensure the antennas have clear line of site to the Controller!!!!**

# ⟨Installation⟩

## LED Enhancement Rings

The supplied LED enhancement rings (wrong way or do not enter) are designed as a cohesive ring that affixes to the face of the respective sign. A single wire exits the top left or right of the ring; no hardware or cabling are visible on the back of the sign.

To attach the ring, peel and stick the adhesive backing to the sign. It is highly recommended that the sign be cleaned with the supplied alcohol wipes before adhering the ring.



## Controller

**Critical-The controller has two antennas that must be installed before power is applied!**

**If utilized, the radar must be attached before power is applied**

The controller should be located on the post or infrastructure so that all supporting components can be connected with the supplied lengths of cable and conduit.

It is also important to consider camera aiming. See the next segment for more info

The controller features two mounting tabs, top and bottom, that are spaced on 1" centers for mounting directly to square posts. Alternatively, banding brackets can be used in the same location

## (Installation)

### Camera Aiming (applies to M75-DETCA-M000 only)

The camera provides critical information about a wrong way event. As such, proper aiming is important to provide as much information as possible. From our experience, the most alarming video evidence is when a wrong way driver's headlights are captured; so we recommend that the camera be aimed **into** wrong-way traffic. An added benefit to this aiming is the potential to see the source of the wrong way driver. Traffic engineers have used this data to advise and justify physical changes to the road to prevent future incidences.

The camera is manually aimed, zoomed, and focused, but can be hard to visualize without seeing the result. During the configuration phase, we will explore how to locally stream the camera's footage.



### Power Supplies

It is highly advised that AC power be utilized where possible to ensure maximum reliability. However, where AC power is not accessible, other options are available.

### Power Supplies, cont'd

The Controller can operate on any 12V source supplying about 6 amps of power. We spec (and supply) the following options:

- Outdoor rated AC inverter
- Battery charger kit that can operate off timed street lamps
- Large solar kits to provide completely off-grid power

Many systems use a combination of power- AC at the Controller and solar power at the Collaborators

Unlike the Controller, the Collaborators are configured for their specific power type and feature built-in components to support the supplied power.

AC Collaborators receive AC power terminated directly inside the unit.

Solar powered units feature a 13Ah extreme temperature battery built into the unit. A 20W, 30W, or 60W panel can be supplied to charge the battery. All charging circuitry is integrated into the unit. A single wire runs from the solar panel into the box.

Where solar power is utilized, ensure that the solar panels are south-facing and angled at 45° (off of level). A calculation typical to solar installation can be utilized to measure an exact angle specific to your latitude.



example of solar setup, from the ground

# (Installation)

## Radars

Much of the system's success or failure relies on the radar's aiming and configuration. Some of this will be a matter of trial and error on every site, but some guiding principals will help...

The radar can detect a wrong way vehicle driving toward it or away from itself. The configuration will designate the desired function.

The radar should be mounted as high as possible on the post or infrastructure. Height maximizes the unit's ability to be aimed correctly and to exclude periphery activity not constituting wrong way driving.

Nothing (Controller, solar panel, signage, etc.) should obstruct the immediate face of the radar.

As much as possible the radar's view should be minimally obstructed by nearby signage, buildings, or foliage. Such objects can cause dead spots, reflections, or small motions that will obfuscate functionality.

The radar mounting bracket accomodates a great angular adjustment of the radar. As shown at right, it can be rotated both up and down, as well as left and right to achieve an accute (45°, typically) aiming at the roadway.

You want the radar to spotlight a small section of roadway about 60' (183m) in front of the post. Higher aiming (broadcast) will produce false detections that are difficult to exclude with configuration settings.



## (Installation)

### Signage

With the LED enhancement applied the sign will mount as any other road sign. It is important that the cable exit the ring at the top left or right corner.

Hardware to mount the signs is not supplied, but readily available at any hardware store or sign supply shop.

### Making Connections

Within the Controller and Collaborator are labeled headers for each connection. No other connections within the box will need to be made, as these are all connected and tested at the time of shipment. If applicable, the battery terminal block may need to be connected.



Controller



Solar Collaborator



AC Collaborator

Our components utilize quick capture connections. To terminate a wire, strip the wire back 10mm, depress the orange tab on the terminal, insert the wire, and release the tab. The whole green connector block may be removed to ease connections.

**All the Collaborators in a group can be powered on at any time. However, due to a 2 hour security time out, it is advised that the Controller be powered on in the final stage of installation.**

## Overview

Configuration is compatible with any wi-fi enabled device. This includes smartphones, tablets, and PCs.

2-5 minutes after being powered on, the Controller will activate a wi-fi network (identified as a unique id containing WWA") available for connection. Connect to this network as any other, through your device's wi-fi settings. You will need to use the following password:

**Tr@ffiCalm** (case sensitive)

The device will warn you that no internet connection is available; this is expected and should be excused. Open the web browser of choice (Explorer, Chrome, Safari, and Edge have been tested functional) and navigate to:

**Setup.trafficalm.com**

You will be prompted for the following password:

**Tr@ffiCalm**

The setup wizard will take you step by step through the system configuration and setup.

Configuration will be in the following order:

- Flashing Options
- Alert Zone Setup
- Flasher Activation Zone Setup
- Pre-Alert Zone Setup
- Confirmation Zone Setup
- Flasher Only Setup
- Advanced Options
- Camera Aiming (applies to M75-DETCA-M000 only)

The configuration wizard is fairly self explanatory, but the following pages are the highlights...

## Setup Wizard

You will set up the Alert zone first as this contains the Controller. The radar can be set to either approaching or receding, set in whatever direction a wrong way driver would be detected by the radar. The default radar sensitivity settings typically suffice. The radar angle and zone size will need to be adjusted according to the system's phys properties.

The zone size can be measured by walking at the radar and observing the diagnostic lights on its face. When the light turns red, detection has begun (mark this location on the road). When the light extinguishes, detection has concluded (again, mark this location). Measure and enter the distance between the two marks.



If present, you can add a Collaborator's ID (ie. 0E23DB) in the Alert Zone and set it up like the Controller.

The final selection on the Alert Zone page will be what other zones will be utilized and how they will collaborate. Select the radio button next to each desired zone and select the collaboration option from the drop down menu.

### Setup Wizard

Don't be alarmed, the next screen will look exactly the same as the previous; the exception being that it is now titled PRE-ALERT ZONE SETUP. The settings are similar, but specific to the two Collaborators you are setting up. An example of the Collaborator ID is seen below. Every Collaborator has one, and they should be noted before installation, they can prove difficult to read from the ground



In the Pre-Alert Zone Setup, the distance of the zone (as previously explained) must be set. Additionally, the distance between the Pre-Alert Zone and the Alert Zone must be designated. Measure the zones center to center to come up with this number.

Finally, select whether the two radars within the zone require collaboration. Leaving this box unchecked will create a zone where a detection on **either** radar constitutes a collaboration. Remember, a notification will not be sent off of a single zone collaboration.

The Flasher Activation and Confirmation Zone Setup pages will be identical in function. Again, each can be setup with 1 or 2 Collaborators.

## <Configuration>

### Setup Wizard

The final step in the Setup Wizard is adding “flasher only” Collaborators. These are devices that do not connect to a radar; they only serve the purpose of flashing connected signage. This setup allows for expansion of the system’s warning beyond just the 4 detections zones.

### Camera Aiming (applies to M75-DETCA-M000 only)

The camera’s footage can be streamed wirelessly to your PC, phone, or tablet for aiming purposes.

To access the camera navigate to the following IP address:

**192.168.0.50**

The camera utility will prompt you for the following username and password:

**User: admin**

**Password: admin**

The live feed from the camera will immediately be visible. To adjust the camera’s aim, simply loosen the set screws securing the elbow in place. Take care as these set screws are small, stainless steel screws and can strip easily. Zooming and focusing are accomplished with manual adjustments made with the housing access panel on the bottom of the camera.

Once the desired aim is achieved, replace the desiccant packet, close the access panel, and check all fittings for tightness.

### Advanced Wizard Page

The advanced page has two options and a stream of the system’s radar detection. A properly setup system will sit idle and have very few radar detections. If a large number of detections are presented, it may be required to re-aim the radars or set the sensitivity settings to less sensitive (more filtering).

## Validation Testing

After setup has been finalized it is important to test the system. The first phase of testing should be to observe any sources of radar “noise” and to adjust the settings and aim to exclude this noise.

The system can be “reversed” to test on live “right-way” traffic. Alternatively, and preferably, the road section should be shut down and live wrong-way testing be performed. We have developed the following test script for reference...

### Wrong Way Alert Test Script

released: 20190815

Where ramp closure is not possible

Procedure- Where RSUT closure is not permissible; it is feasible to test the system off of active, right way traffic. The control of speed and traffic volume is inherently impossible in this scenario. System test will rely on sufficient observation of traffic activating the system from specific lanes of entry. It is advised that tests occur during hours that traffic is expected to be low; specifically, gaps between passing vehicles results in improved accuracy and is most indicative of an average wrong way event. With the assistance of TrafficCalm systems team, these tests can be performed remotely. To perform this test, the system will be set up in “reverse” of its final configuration. For example, a system consisting of 2 radars in the Pre-Alert Zone and 2 radars in the Alert Zone, all detecting approaching traffic (wrong way traffic) will be configured with 2 radars in the Confirmation Zone and 2 radars in the Alert Zone, all set to detect receding traffic. It is critical that the detection aiming remains identical throughout the test to ensure proper operation in Wrong Way mode. Once the test is complete, the system can be configured to wrong way mode by reversing the changes set.

Run description	Pass?	Time to Notify	Notes
Lane 1			
Lane 2			
Lane 3			
Lane 1+2			
Lane 2+3			
Lane 1+3			

#### Notes

This test can be expanded to as many lanes of entry as necessary, we have limited it to three (3) only for reference. Where alternative methods of detection are utilized (loops, push buttons, etc) the test will still be effective, though additional hardware settings may be required on the detection hardware. We have seen this test expanded upon, with different vehicle sizes noted, expanded speeds added, and additional environmental influences (trains in motion, for example) considered, consider this a starting point for your own tests.

## Wrong Way Alert Test Script

released: 20190815

Given the variability of ramps and roadways that Wrong Way Alert can cover, it is important to properly test and verify system functionality. In our experience, a concise test plan results in effective performance measures that can be relied upon for real world monitoring of dangerous wrong way events. This script is the result of working with dozens of transportation engineers on real projects and we feel it is comprehensive, but local knowledge and regulations should be considered when implementing your own test plan. Note that this procedure is intended to be used after the system has been configured. All tests should result in a full notification and warning devices being illuminated.

---

---

### Where ramp closure is feasible (recommended)

---

---

Procedure- Per governing guidelines, the road section under test (RSUT) shall be closed to permit sufficient and safe passage of a single vehicle traveling the wrong direction at up to 45mph through all potential lanes of entry; this may include medians and shoulders. The result should be twofold- complete coverage resulting in notifications being sent from any possible wrong way driving scenario, and no false detections after the RSUT is opened to live traffic. If a fail occurs, it is (typically) reasonably acceptable to adjust radar aiming and configuration, and then restart the test.

Run description	Pass?	Time to Notify	Notes
10mph, lane 1			
25mph, lane1			
35mph, lane1			
45mph, lane1			
10mph, lane 2			
25mph, lane2			
35mph, lane2			
45mph, lane2			
10mph, lane 3			
25mph, lane3			
35mph, lane3			
45mph, lane3			
25mph, Cross Lanes			

### Overview

The net result of a reliable wrong way mitigation system is trustworthy notification, if equipped. A system that delivers false notifications too frequently will dilute its own effectiveness.

Additionally, the effectiveness of the notification relies on the recipient's ability to view and interpret it. At the guidance of two state-wide monitoring centers, we developed a network of notifications that do not rely on constant monitoring. The three options for notification are:

1. Email on any device and to any email address
2. BlueSentry Web Interface
3. Standalone TMC *Notifier*

The most basic of the three is via Email. Due to its ubiquity, it is the most commonly adopted method of notifying. Within 20 seconds of a successfully collaborated detection a full color, 18 second video will be delivered for review. The email subject line contains the location and information pertinent to the event and the attached video serves as fool-proof confirmation of an actual event. The email also includes a link to our BlueSentry interface

Active all of the time, BlueSentry is a constant monitor of all connected wrong way systems in your group. Individual user permissions can be setup so that every operated appears as a unique visitor (important when the history of detections and whom cleared them is reviewed). BlueSentry is a straightforward interface that makes navigating alerts and systems very intuitive.

If immediate, closed-loop monitoring is desired, our standalone TMC Notifier is a wireless device connected directly to our server that receives notifications in real time. Connected to any HDMI monitor, it can serve as dramatic audible and visual warning in the hectic environment of a monitoring center.

# <Notification Monitoring>

**TRAFFICALM**  
SYSTEMS

NC540 Toll SB @ Salem  
Status: alarm!



## Example of Notification

### Notification Run Down

The screenshot above shows a typical alarm setup, the road section is designated, the screen turns red, and the 18 second video clip plays on loop until the event is cleared by an operator.

### Finally, Maintenance

Maintenance for our system is very easy...

- Renew Notification Contract every 2 years
- Watch for low power or offline notifications
- Periodically clear the radar faces and solar panels of snow, dust, and debris
- Inspect and replace Collaborator Batteries about every 3 years
- Inspect systems for damage or radar mis-aiming after being struck or after heavy storm
- Inspect systems that sustain flashing







For Any Further Assistance  
Please Call our Technical  
Service Department  
855-738-2722

[www.trafficalm.com/wwwa](http://www.trafficalm.com/wwwa)